


ENGAGE

TO ENENGAGE:


1. ANGLE

- Start by engaging the plank on the long side at a 45° degree angle.




2. SLIDE

- Slide the plank to the left until the sides align.




3. DROP

- Gently drop the plank to engage the locking system.




4. CLICK

- Press along the short side until you hear or feel the plank “Click” into place.




5. SECURE

- To secure the locking system and make flush, gently tap with a soft-faced hammer.



6. CHECK

- If planks are not completely flush, repeat step 5.




DISENGAGE

TO DISENGAGE:


1. SLIDE

- Slide the planks in the opposite direction to disengage.



2. DROP

- If planks are not disengaging, then tap with a soft-faced hammer and then slide planks.



WARNING!

- Do not angle the planks to disengage. The locking system will break.

